

Food Warmer Display

USER MANUAL

EN



Model: SWHA
SWHB
SWHC
SWHD

Thank you for choosing Slightwind's products.

CONTENTS

INTRODUCTION	3
PRODUCTION PURPOSE:	3
STANDARD FEATURES:	3
CONTACT INFORMATION:	3
IMPORTANT SAFETY INFORMATION:	4
SPECIFICATIONS	5
OPERATING MANUAL	6
INSTALLATION:	6
OPERATION:	6
CLEANING AND MAINTENANCE:	7
TROUBLESHOOTING:	8
PARTS DIAGRAM AND LIST	9

INTRODUCTION

PRODUCTION PURPOSE:

Food safety and preserving food is the purpose, The Nguyen Phuong company with Slightwind® brand developed and manufactured Food Warmer Display with advanced features and utilities in use.

Food Warmer Display is the solutions for cafeterias, clubs & bars, concessions, convenience stores, restaurants and supermarkets & delis.

STANDARD FEATURES:

- Temperature can adjust **37°C – 75°C** with commercial resisting heating system.
- The heating element is located upper accordance with the standards of the commercial food warmer and keep the product temperature always stable.
- Your food product will be displayed better than to the light bulb.
- The temperature of each compartment can adjusted independently to suitable for various food.
- Some accessories can disassemble easily to cleaning or transportation conveniently.
- Super clear tempered glass with high durability and safety.
- Material surface in direct contact with food is made of SUS304.
- The product is specifically designed for commercial equipment.
- All models are shipping included with adjustable legs, cord plug, trays and grid trays.

CONTACT INFORMATION:

- For service, purchase: 0919.120.068
- For technical issues:
 - Ho Chi Minh City: 0919.120.068
 - Ha Noi City: 0936.104.698
 - Hue City: 0933.524.133
 - Email: nguyenphuong@slightwind.com.vn









Additional information can be found by visiting our website at www.slightwind.com.vn

IMPORTANT SAFETY INFORMATION:

The instructions in this manual cannot cover all possible conditions and situations that may occur. Read carefully and understand all USER MANUALs before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

- Use only grounded electrical outlets matching the nameplate rated voltage: 220V
- Use equipment in a flat, level position.
- Unit is not weatherproof. Locate unit sheltered place and exposure to rain water.
- Unplug unit, turn off and allow unit to cool before cleaning, maintenance or moving.
- Discontinue use if power cord is frayed or worn.
- Keep unit and power cord away from open flames, electric burners or excessive heat.
- **DO NOT** touch or put anything on the unit roof when it is operating to avoid burn.
- **DO NOT** plug this unit into multi-outlet power cord.
- **DO NOT** spray controls or outside of unit with liquids or cleaning agents.
- **DO NOT** spray the heating element or outside of unit with liquids or cleaning agents.
- **DO NOT** allow children to come into touch unit while it is operating.
- **DO NOT** operate if unit has been wet.
- **DO NOT** operate if unit has been damaged or is malfunctioning in any way.
- It is essential to use genuine Replacement Parts when repairing equipment. Failure to use genuine Replacement Parts may subject operators of the equipment to hazardous electrical voltage, resulting in electrical shock or burn.

SPECIFICATIONS

Model	SWHA 	SWHB 
Dimension (W x D x H)	 800 x 395/600 x 760mm	 900 x 560 x 700mm
Material	Stainless steel Tempered glass Polycarbonate	Stainless steel
Temperature	From 37°C to 80°C	From 37°C to 75°C
Voltage	220-240V-50Hz-1Ph	220-240V-50Hz-1Ph
Wattage	1320W	1320W
Model	SWHC 	SWHD 
Dimension (W x D x H)	 900 x 450/750 x 860mm	 800 x 350/500 x 550mm
Material	Stainless steel Polycarbonate	Stainless steel Tempered glass
Temperature	From 37°C to 80°C	From 37°C to 75°C
Voltage	220-240V-50Hz-1Ph	220-240V-50Hz-1Ph
Wattage	1320W	1310W

OPERATING MANUAL

INSTALLATION:

1. Remove unit from box
2. Remove tape and protective iron frame from all (Model SWHA and SWHD)

3. Assemble adjustable legs of the equipment.




4. Locate unit on a table or flat position.

Note:

- Locate the unit at the proper counter height, in an area that is convenient for use.
- Keep unit and power cord away from open flames, electric burners or excessive heat.
- Unit is not weatherproof. Locate unit indoors.

OPERATION:

1. Connect unit to the power supply.



2. Turn on the lighting switch from "OFF" to "ON"

ON/OFF
Toggle Switch

Temperature
Control



3. Adjust temperature to the value to be set.

4. Put the food in the food tray.
5. Place the food tray in the equipment.



Note:

- DO NOT put the food directly on the surface of the equipment.
- Food needs to be put in a box or in a food tray.
- **DO NOT** store food with plastic materials or are prone to deformation when encountering high temperatures.
- **Do NOT** keep food continuously for more than 2 hours in the device with high temperature.
- It is advisable to keep the cooked food warm only.
- There is an appropriate heating temperature with another food to keep warm. However, to ensure food safety and preserving food, the recommended temperature should be 40°C or more.
- Use tongs or wear gloves to move food and avoid burns when the unit is operating.


CLEANING AND MAINTENANCE:

- Turn off, unplug unit and allow unit to cool before cleaning, maintenance or moving.
- **DO NOT** spray unit with liquids or cleaning agents.
- **DO NOT** submerge in water. Unit is not waterproof. **DO NOT** operate if unit has been wet.
- **DO NOT** clean the unit with steel wool.
- Use only non-abrasive cleaners. Abrasive cleaners could scratch the finish of your unit, marring its appearance and making it susceptible to dirt accumulation.
- Only soft cleaning cloths, mild soap and water or specialized cleaners should be used to clean surfaces the unit.
- Clean glass surfaces with a common glass cleaner.
- Regularly clean the unit so that it is ventilated and works efficiently.
- After using: turn off and unplug unit; cleaning outside and inside the unit.

TROUBLESHOOTING:

Problem	Probable cause	Remedy
Food cavity is too hot	Heat controls are set too hot	Adjust heat controls to a lower setting
	Heat controls are not working	Contact company service for assistance.
Food cavity is not hot enough	Heat controls are set too cool	Adjust heat controls to a higher setting
	Heat controls are not working	Contact company service for assistance.
	Heating elements are not working	Contact company service for assistance.
Unit is not hot	Heating elements are defected	Contact company service for assistance.
	Heat controls is defected	Contact company service for assistance.
	Units is not connected to power supply	Check the power supply
No heating and no lighting	The switch ON/OFF is in OFF position.	Turn switch to ON position.
	There is no power to units	Check the power supply
	Heating elements and lights are defected	Check the heating element and lights


PARTS DIAGRAM AND LIST



Model : SWHA


Item	Hạng mục	Project name Dự án	Model : SWHA		QTY/SUBQTY	SCALE/TL
			PRODUCE/S.XUẤT	CUSTOMER/K.HÀNG		
	DIRECTOR/G.ĐỐC	DESIGNER/T.KẾ	PRODUCE/S.XUẤT	CUSTOMER/K.HÀNG	01 ĐỢ	1:1
	NGUYỄN DUY PHƯƠNG	NGUYỄN ĐÌNH HUY	BUI THANH TÙNG		DATE/NGÀY	BASE/BO S. TRANG
	KY XÁC NHẬN	KY XÁC NHẬN	KY XÁC NHẬN			1
						PRODUCT/S. PHẨM
						FOOD WARMER SWHA SWHA

SLIGHT WIND
 NGUYỄN DUY PHƯƠNG
 CÔNG TY TNHH TM-DV-SX
 NGUYỄN ĐÌNH HUY
 62 PHAN ĐÌNH PHÙNG, P. TÂN THÀNH
 Q. TÂN PHÚ, TP. HỒ CHÍ MINH




Model : SWHB

SƠ ĐỒ MẠCH ĐIỆN TỦ GIỮ NÓNG SWHB



ITEM NO.	DESCRIPTION	Part Number	QTY.
1	Tấm Kê Trên	SWB21.001	1
2	Bóng Đèn Chiếu Sáng	SWC1.003	8
3	Điện Trở Đốt Nóng	SWC1.004	2
4	Tấm Hông Phải	SWB21.002	1
5	Tấm Kê Giữa	SWB21.003	1
6	Tấm Hông Trái	SWB21.004	1
7	Bảng Điện Điều Khiển	SWB21.005	2
8	Công Tắc Nguồn	SWC1.008	1
9	Điện Bảo Điện Trở Hoạt Động	SWC1.011	2
10	Bộ Điều Khiển Nhiệt Độ	SWC1.010	2
11	Núm Xoay Bộ Điều Khiển Nhiệt Độ	SWC1.009	2
12	Tấm Đáy	SWB21.006	1
13	Chân Tăng Đỡ	SWC1.016	4



**CÔNG TY TNHH TM-DV-SX
NGUYỄN PHƯƠNG**
50 NGUYỄN XUÂN KHOÁT, P. TÂN THÀNH
Q. TÂN PHÚ, TP. HỒ CHÍ MINH

Item Hạng mục: DIRECTOR/G. ĐỐC

Project name Dự án: NGUYÊN DUY PHƯƠNG

QTY/SLƯỢNG: 01 BỘ

SCALE/TỈ LỆ: 1:1

DATE/NGÀY: S. TRƯƠNG

PAGE/NO S. TRANG: 1


Model : SWHB

PRODUCE/S. XUẤT: CUSTOMER/K. HÀNG


BUY THANH TÙNG

KÝ XÁC NHẬN: KÝ XÁC NHẬN

PRODUCT/S. PHẨM: FOOD WARMER SHOWCASE SWHB



Model : SWHC





SƠ ĐỒ MẠCH ĐIỆN TỦ GIỮ NÓNG SWHC

ITEM NO.	DESCRIPTION	Part Number	QTY.
1	Tấm Kệ Trên	SWC21.001	1
2	Tấm Cửa Tủ	SWC21.002	8
3	Điện Trở Đốt Nóng	SWZ1.004	2
4	Bóng Đèn Chiếu Sáng	SWZ1.003	6
5	Tấm Hông Trái/ Phải	SWC21.005	2
6	Tấm Đáy	SWC1.001	1
7	Tấm Kệ Giữa	SWC21.005	2
8	Công Tắc Nguồn	SWZ1.008	2
9	Đèn Báo Điện Trở Hoạt Động	SWZ1.011	2
10	Bộ Điều Khiển Nhiệt Độ	SWZ1.010	2
11	Núm Xoay Bộ Điều Khiển Nhiệt Độ	SWZ1.009	2
12	Bảng Điện Điều Khiển	SWC21.006	2
13	Chân Tăng Đỡ	SWZ1.016	4

Item Hạng mục	Project name Dự án	Model : SWHC		QTY/SCDWG 01 BỘ	SCALE/TL 1:1
	DIRECTOR/G.ĐỐC	DESIGNER/T.KẾ	PRODUCE/S.XUẤT	CUSTOMER/K.HÀNG	PAGE/TO 9. TRANG
NGUYỄN DUY PHƯƠNG KỶ XÁC NHẬN	NGUYỄN ĐÌNH HUY KỶ XÁC NHẬN	BÙI THANH TÙNG KỶ XÁC NHẬN		PRODUCT/S. PHẨM FOOD WARMER SHOWCASE SWHC	
	KỶ XÁC NHẬN		KỶ XÁC NHẬN		FOOD WARMER SHOWCASE SWHC

SLIGHT WIND
WINDMILL AND COOKER LTD
 CÔNG TY TNHH TM-DV-SX
NGUYỄN PHƯƠNG
 50 NGUYỄN XUÂN KHOÁT, P. TÂN THÀNH
 Q. TÂN PHÚ, TP. HỒ CHÍ MINH

SƠ ĐỒ MẠCH ĐIỆN TỬ GIỮ NÓNG SWHD



ITEM NO.	DESCRIPTION	Part Number	QTY.
1	Tấm Kệ Trên	SW21.001	1
2	Bảng Điện Điều Khiển	SW21.002	1
3	Điện Trở Đốt Nóng	SW21.004	2
4	Bóng Đèn Chiếu Sáng	SW21.003	2
5	Kính Cường Lực Cảnh Bên	SW21.005	2
6	Óp Che Cảnh Bên	SW21.001	2
7	Tấm Mặt Trong Kệ Dưới	SW21.006	1
8	Nẹp Giữ Kính	SW21.006	2
9	Kính Cường Lực Trước, Sau	SW21.007	2
10	Tấm Đáy	SW21.008	1
11	Chân Tăng Đỡ	SW21.018	4
12	Núm Xoay Bỏ Điều Khiển Nhiệt Độ	SW21.009	1
13	Bộ Điều Khiển Nhiệt Độ	SW21.010	1
14	Đèn Báo Điện Trở Hoạt Động	SW21.011	1
15	Công Tác Nguồn	SW21.008	1

Model : SWHD

Item Hạng mục	Project name Dự án	Model : SWHD	QTY/SUỐI	SCALE/TL
DIRECTOR/G.ĐỐC	DESIGNER/T. KẾ	PRODUCE/S. XUẤT	01 BỘ	1:1
NGUYỄN DUY PHƯƠNG	NGUYỄN ĐÌNH HUY	CUSTOMER/K. HÀNG	DATE/NGÀY	PAGE SỐ S. TRANG
KÝ XÁC NHẬN	KÝ XÁC NHẬN	BỘT PHANH TÙNG		1
		KÝ XÁC NHẬN		
		KÝ XÁC NHẬN		
				PRODUCT/S. PHẨM
				FOOD WARMER SHOWCASE SWHD



CÔNG TY TNHH TM-DV-SX
NGUYỄN PHƯƠNG
 50 NGUYỄN XUÂN KHOÁT, P. TÂN THÀNH
 Q. TÂN PHÚ, TP. HỒ CHÍ MINH

COLD STORAGE



Food Warmer Display
SWHB Series



Food Warmer Display
SWHC Series



Food Warmer Display
SWHA Series



Food Warmer Display
SWHD Series

NGUYEN PHUONG SERVICES TRADING PRODUCTION COMPANY LIMITED

Office: 62A Phan Dinh Phung Str, Tan Thanh Ward, Tan Phu Dist, HCMC
Ha Noi Branch: 39 Lo Duc Str, Pham Dinh Ho Ward, Hai Ba Trung Dist, Ha Noi City
Hue Branch: 22/2 Phu Mong Str, Kim Long Ward, Hue City, Thua Thien Hue Province
Factory: 79/2D Thoi Tam Thon 18 Str, Thoi Tam Thon Commune, Hoc Mon Dist, HCMC